

LETTURA DEL DISPLAY

PULSANTI	FUNZIONE PRINCIPALE
Pulsante ON/OFF (logo Standby)	Acceso / Spento, ed esce dal menù
MODE	Accesso alla configurazione, impostazione set, ventilazione automatica/manuale, funzionamento riscaldamento/condizionamento, password menù abilitazioni, memorizza ed esce del menù
Freccia SU	Incrementa valori numerici
Freccia GIU'	Decrementa valori numerici

SIMBOLI DEL DISPLAY	SIGNIFICATO
Temp °C (scritta grande)	Temperatura misurata
Set Temp. °C (scritta piccola)	Set Temperatura impostata
Ventola in movimento	Ventilazione ON
Ventola ferma	Ventilazione OFF
Ventola intermittente	Temperatura acqua in batteria non raggiunta
Scala indicatrice	Set percentuale ventilazione (1-100%)
Sole - Warm	Modalità inverno (riscaldamento) temperatura 5÷35°C
Fiocco di neve - Cold	Modalità estate (raffrescamento) temperatura 5÷80°C
Orologio 1	Impostazione Timer 1 attiva (con scheda orologio installata, optional)
Orologio 2	Impostazione Timer 2 attiva (con scheda orologio installata, optional)
Omino	Presenza persona in stanza (se il contatto presenza nella scheda H109 è collegato)
Spicchio di luna	Abbassamento temp. notturna attivato (con scheda orologio installata, optional)

DISPLAY READING

KEYS	MAIN FUNCTION
ON/OFF key (Standby logo)	On/Off, and exits menu
MODES	Access to the configuration, set point, automatic/manual ventilation, heating/air conditioning operation, password for enabling menu, saves and exits the menu
UP arrow	Increases numeric values
DOWN arrow	Decreases numeric values

DISPLAY SYMBOLS	MEANING
Temp°C (large text)	Temperature measured
Set Temp.°C (small text)	Set temperature
Fan running	Ventilation ON
Fan stopped	Ventilation OFF
Intermittent fan	Water temperature in coil not reached
Indication range	Ventilation percentage setting (1-100%)
Sun - Warm	Winter mode (heating) temperature 5÷35°C
Snowflake - Cold	Summer mode (cooling) temperature 5÷80°C
Timer 1	Timer 1 setting active (with timer card installed, optional)
Timer 2	Timer 2 setting active (with timer card installed, optional)
Figure	Person in room (if the presence detection contact in the H109 card is connected)
Crescent moon	Night-time temperature decrease enabled (with timer card installed, optional)